

Tools Required

- cordless drill
- drill bit - #2 Robertson

1. The drum base includes a sub top larger than the base. The sub top has pre-drilled holes around the outside.
2. Center the table top on top of the sub top, finished side up.
3. From the underside, screw through the sub top into the table top with the provided screws.

